

# Reset Engine Oil Replacement Reminder Light

2007 Model Year Toyotas

<b>Model</b>	<b>Reset Reminder Light Procedure</b>
'07 tC  Page 108	<p>The system must be reset after the engine oil replacement. Reset the system by the following procedure:</p> <ol style="list-style-type: none"><li>1. Turn the ignition key to the "OFF" position with the odometer reading shown. (For details, see "Odometer and two trip meters" on page 103.)</li><li>2. Turn the ignition key to the "ON" position while holding down the trip meter reset knob.</li></ol> <p>Hold down the knob for at least 5 seconds. The odometer indicates "000000" and the light goes off.</p>